




# CE407 SEPARATIONS




Lecture 21

Instructor: David Courtemanche

# Packed Towers




# Packed Towers



# Packed Towers


- Analyze a slice of the tower from height  $z$  to  $z + \Delta z$
- The control volume is the irregularly shaped volume around the wetted packing
  - i.e. the gas around the wetted packing





# Control Volume Analysis

- Rate of solute entering control volume from below (via the gas) =  $Vy|_z$ 
  - Where  $V$  is the molar flow rate of gas and  $y$  is the bulk vapor mole fraction of solute evaluated at height  $z$
- Rate of solute exiting control volume at top (via the gas) =  $Vy|_{z+\Delta z}$ 
  - Evaluated at height  $z + \Delta z$




## Control Volume Analysis, continued

- Rate of solute exiting the gas due to absorption across the gas/liquid interface

$$flux = \frac{\text{moles}}{\text{area} * \text{time}} = \underbrace{k_y(y - y_i)}_{\text{interfacial area per volume of packed tower}} * \underbrace{a S \Delta z}_{\text{cross sectional area, } S, \text{ times thickness of slice = volume of slice}}$$

- $a S \Delta z$  therefore is the area available for mass transfer in the control volume
- $k_y(y - y_i) * a S \Delta z$  therefore has dimensions of moles/time – rate of mass transfer
- NOTE:  $a$  is NOT just the surface area/volume of the packing. It is the gas/liquid interfacial area per packed volume of the wetted packing and is a function of flow rate
  - The thickness of the liquid layer depends on the flow rate and the actual surface area of the liquid wetting the packing depends on the thickness of that layer.
- $y_i$  is the mole fraction of the vapor phase at the gas/liquid interface



# Control Volume Analysis, continued

- At steady state:

Moles solute in = moles solute out

$$Vy|_z = Vy|_{z+\Delta z} + k_y(y - y_i) * a S \Delta z$$


- Therefore

$$\frac{Vy|_{z+\Delta z} - Vy|_z}{\Delta z} = -k_y a S (y - y_i)$$

- Take the limit as  $\Delta z \rightarrow 0$

$$\frac{d}{dz}(Vy) = -k_y a S (y - y_i)$$

- Note: gas is losing solute as you go up the tower (increasing  $z$ ), which agrees with the fact that the right hand side of the equation is negative



## Control Volume Analysis, continued


- For a dilute mixture  $V \approx \text{constant}$ , so we can take it out of the integral

$$V \frac{dy}{dz} = -k_y a S (y - y_i)$$

- Now we separate the variables

$$dz = -\frac{V/S}{k_y a} \frac{dy}{y - y_i}$$

- Integrate from the bottom of the tower





# Control Volume Analysis, continued

- Integrate left hand side of the equation

$$\int_0^{Z_t} dz = Z_t$$

- Evaluate the RHS

$$Z_t = -\frac{V/S}{k_y a} \int_{y_b}^{y_a} \frac{dy}{y - y_i}$$


- Reversing the limits on the integral will change the sign

$$Z_t = \underbrace{\frac{V/S}{k_y a}}_{\text{Height of a Transfer Unit}} \underbrace{\int_{y_a}^{y_b} \frac{dy}{y - y_i}}_{\text{Number of Transfer Units, } N_y}$$

- $$H_y = \frac{V/S}{k_y a}$$

Height of a Transfer Unit      Number of Transfer Units,  $N_y$

Because we have been working in Vapor Phase mole fractions, this carries the subscript y




# Control Volume Analysis, continued

$$Z_t = H_y * N_y$$

$$H_y = \frac{V/S}{k_y a}$$

$$N_y = \int_{y_a}^{y_b} \frac{dy}{y - y_i}$$

- The height of packing required ( $Z_t$ ) is the product of the height of a transfer unit ( $H_y$ ) times the number of transfer units ( $N_y$ )
- Height of a transfer unit can be thought of as: Given the flows / mass transfer coefficient / available surface area per volume – how effective is a packing
- Number of transfer units can be thought of as: how much mass transfer do we need to accomplish
- This may look straightforward to solve, except:
  - How are we going to determine  $a$  ?
  - How do we determine  $y - y_i$  as a function of  $y$  in order to evaluate the integral?



# Number of Transfer Units

$$N_y = \int_{y_a}^{y_b} \frac{dy}{y - y_i}$$

- If  $y - y_i$  is constant then we can take it out of the integral
  - $N_y = \frac{1}{y - y_i} \int_{y_a}^{y_b} dy = \frac{y_b - y_a}{y - y_i}$  which is  $\frac{\text{total concentration change in tower}}{\text{driving force for mass transfer}}$
- If  $y - y_i$  is not constant
  - one can numerically integrate: will need multiple data points for  $y_i$  vs  $y$
  - one can use an average value of  $y - y_i$ : use Logarithmic Mean

$$\overline{(y - y_i)}_{lm} = \frac{(y - y_i)_a - (y - y_i)_b}{\ln \left[ \frac{(y - y_i)_a}{(y - y_i)_b} \right]}$$

$$N_y = \frac{y_b - y_a}{\overline{(y - y_i)}_{lm}}$$



# How do we sort out the interfacial mole fraction?

- At Steady State

$$\left[ \begin{array}{l} \text{Flux of Solute from Bulk} \\ \text{Gas to the Interface} \end{array} \right] = \left[ \begin{array}{l} \text{Flux of Solute from Interface} \\ \text{to Bulk Liquid} \end{array} \right]$$


- and...  $y_i = y^*(x_i)$  (Interfacial Mole Fractions are in Equilibrium)
- Which we can express as...

$$k_y(y - y_i) a \Delta V = k_x(x_i - x) a \Delta V$$

  
 Area available for mass transfer

- Which can be rearranged to...

$$y - y_i = -\frac{k_x}{k_y}(x - x_i)$$



# How do we sort out the interfacial mole fraction?

- We know that: 
$$H_y = \frac{V/S}{k_y a} \quad \text{Eq 22-19}$$

- Analogously: 
$$H_x = \frac{L/S}{k_x a} \quad \text{Eq 22-20}$$

- So... 
$$k_x = \frac{L/S}{H_x a} \quad \text{and} \quad k_y = \frac{V/S}{H_y a}$$

- Therefore: 
$$\frac{k_x}{k_y} = \frac{L/S}{H_x a} * \left( \frac{V/S}{H_y a} \right)^{-1} = \frac{L/S}{H_x a} * \frac{H_y a}{V/S} = \left( \frac{L}{V} \right) \frac{H_y}{H_x}$$

- For dilute systems  $\frac{L}{V} \approx \mathbf{constant}$  and is the slope of the nearly straight OP Line

- $\frac{L}{V} \approx \frac{y_b - y_a}{x_b - x_a}$  from previous lectures





## How do we sort out the interfacial mole fraction?

- Now
 
$$y - y_i = -\frac{k_x}{k_y} (x - x_i)$$

$$y - y_i = -\left(\frac{L}{V}\right) \left(\frac{H_y}{H_x}\right) (x - x_i)$$
- Use equilibrium relationship (Raoult's Law, etc) to relate  $y_i$  to  $x_i$ 
  - $y_i = mx_i \rightarrow x_i = y_i/m$
- Now we have one equation and one unknown so we can solve for  $y_i$  in terms of  $x$  and  $y$  at any point in the tower
- Solve for  $y_i$  at the top (a) and bottom (b) of the tower and take log mean of  $(y - y_i)_a$  and  $(y - y_i)_b$
- Now you can solve for number of transfer units
 
$$N_y = \frac{y_b - y_a}{(y - y_i)_{lm}}$$
- Then the height of packing required is  $Z_t = H_y N_y$
- We've still got some issues – we don't know  $a$  and we will need to determine  $k_x$  and  $k_y$**



## Various Forms to Solve for $Z_t$

- Gas Film:

$$H_y = \frac{V/s}{k_y a} \quad N_y = \int \frac{dy}{y - y_i}$$

- Liquid Film:

$$H_x = \frac{L/s}{k_x a} \quad N_x = \int \frac{dx}{x_i - x}$$

- Overall Gas:

$$H_{Oy} = \frac{V/s}{K_y a} \quad N_{Oy} = \int \frac{dy}{y - y^*}$$

- Overall Liquid:

$$H_{Ox} = \frac{L/s}{K_x a} \quad N_{Ox} = \int \frac{dx}{x^* - x}$$

- All of these are equivalent and will lead to the same answer for  $Z_t$
- We still need to figure out mass transfer coefficients and  $a$  !**